





Fig. 1



[図2]

Fig. 2







Fig. 3






Fig. 4A

(a)







Fig. 4B

(b)







キースイッチ	操作	指示信号
キ-13a	保存	キ-ボード「Ctrl」+「S」
キ-13b	全て選択	キ-ボード「Ctrl」+「A」
キ-13c	コピー	キ-ボード「Ctrl」+「C」
キ-13d	カット	キ-ボード「Ctrl」+「X」
キ-13e	ペースト	キ-ボード「Ctrl」+「V」
キ-13f	アンドゥ	キ-ボード「Ctrl」+「Z」
キ-13g	書体設定	キ-ボード「Ctrl」+「D」
キ-13h	新規作成	キ-ボード「Ctrl」+「N」
キ-13i	表示切替	キ-ボード「Alt」+「Esc」
キ-13j	ON/OFF	入力装置の ON/OFF 切替

KEY SWITCH	LABEL	INSTRUCTION SIGNAL
KEY 13a	STORE	KEYBOARD "Ctrl" + "S"
KEY 13b	SELECT ALL	KEYBOARD "Ctrl" + "A"
KEY 13c	COPY	KEYBOARD "Ctrl" + "C"
KEY 13d	CUT	KEYBOARD "Ctrl" + "X"
KEY 13e	PASTE	KEYBOARD "Ctrl" + "V"
KEY 13f	UNDO	KEYBOARD "Ctrl" + "Z"
KEY 13g	FONT SETTING	KEYBOARD "Ctrl" + "D"
KEY 13h	CREATE NEWLY	KEYBOARD "Ctrl" + "N"
KEY 13i	SWITCH DISPLAY	KEYBOARD "Alt" + "Esc"
KEY 13j	ON/OFF	ON/OFF SWITCHING OF INPUT DEVICE




Fig. 7A

(a)




Fig. 7B

(b)




Fig. 7C

(c)





Fig. 7D

(d)






Fig. 8A (a)




Fig. 8D (d)




Fig. 8B (b)




Fig. 8E (e)







Fig. 8C (c)





It is hereby certified that this Response and Amendment is faxed to the examiner at fax number (703)-305-4750, on this 6th day of February, 2004.

2/6/04
Dated

J. Andrew McKinney, Jr.